## The Car Hacker's Handbook

## A Guide for the Penetration Tester

by Craig Smith

## errata updated to print 9

Page	Error	Correction	Print corrected
19	it won't break if another packet transmits extended CAN packets	it won't break if another <b>sensor</b> transmits extended CAN packets	Print 5
19	When looking at extended packets in a network dump, you'll see that unlike standard packets, extended packets use substitute remote request (SRR) in place of the remote transmission request (RTR) with SSR set to 1.	When looking at extended packets in a network dump, you'll see that unlike standard packets, extended packets use substitute remote request (SRR) in place of the remote transmission request (RTR) with SRR set to 1.	Print 5
22	Figure 2-6 replacement	Header Data Bits CRC  P P P H K Y Z Z	Print 5
24	Figure 2-9 replacement	Header Response	Print 5
		Break SYNC ID Data (0-8 bytes) Checksum	
25	MOST divided into the seven layers of the OSI model. The OSI layers are in the right column.	MOST divided into the seven layers of the OSI model. The OSI layers are in the left column.	Print 5

Page	Error	Correction	Print corrected
33	Figure 2-19 replacement	CAN High  Chassis Ground  Signal Ground  CAN Low  CAN Low  PWM –  PWM +  * Power  KWP L-Line	Print 5
43	<pre># sudo insmod ./can-isotp.ko</pre>	<pre>\$ sudo insmod ./can-isotp.ko</pre>	Print 5
45	addr.can_ifindex = ifr.ifr_ifindex;	<pre>addr.can_ifindex = ifr.ifr_ifindex; bind(s, (struct sockaddr *)&amp;addr, sizeof(addr));</pre>	Print 5
55	(If the response fails, you should see a 0x7F instead of the positive + 0x40 response.)	(If the response fails, you should see a 0x7F instead of the positive + 0x40 response.) You can send a request to 0x7DF and it should generate a response from all listening ECUs. This response value will be anything from 0x7E8 to 0x7EF. If you want to address just one ECU directly, you subtract 8 from the response value; for example, if you see a response of 0x7E8 you can use 0x7E0 to query only that ECU.	Print 5
95	It's a good idea to make a list of part numbers to feed to Google, <i>datasheet.com</i> , or something similar, to obtain a copy of the data sheet.	It's a good idea to make a list of part numbers to feed to Google, <i>datasheets.com</i> , or something similar, to obtain a copy of the data sheet.	Print 5
109	The result is the vector table shown in Figure 6-15, which looks sane enough: all addresses are above the 0x8000 entry point specified. Notice that the reset vector (0xFFFE, RES-vector) has a pointer to the RESET_entry at 0xBE6D.	The result is the vector table shown in Figure 6-15, which looks sane enough: all addresses are above the 0x8000 entry point specified. Notice that the reset vector (0xFFFE, RES_vector) has a pointer to the RESET_entry at 0xBE6D.	Print 5

Page	Error	Correction	Print corrected
121	Figure 7-6 replacement	Hall effect sensor  Magnet	Print 5
125	Every so often a CAN signal shows up that resets the values to 00 00 and stops the <b>speedometer</b> from moving.	Every so often a CAN signal shows up that resets the values to 00 00 and stops the <b>tachometer</b> from moving.	Print 5
129	If you look up the model number in conjunction with the ST code, you'll learn that the STM32F407Vx series is an ARM Cortext M4 chip with support for Ethernet, USB, two CANs, and LIN as well as JTAG and Serial Wire Debug.	If you look up the model number in conjunction with the ST code, you'll learn that the STM32F407Vx series is an ARM Cortex M4 chip with support for Ethernet, USB, two CANs, and LIN as well as JTAG and Serial Wire Debug.	Print 5
163	The algorithm in Listing 9-3 reads in a byte at <b>①</b> , multiplies it by 5 at <b>②</b> , and then, at <b>③</b> , adds it to the hash to calculate the final sum.	The algorithm in Listing 9-3 reads in a byte at <b>①</b> , shifts left by 5 at <b>②</b> , and then, at <b>③</b> , adds it to the hash to calculate the final sum.	Print 5
195	\$ gcc -0 temp_shellcode temp_shellcode.c \$ ls -1 temp_shell -rwxrwxr-x 1 craig craig 8722 Jan 6 07:39 temp_shell \$ ./temp_shellcode  Now run candump in a separate window on vcan0, as shown in the next listing. The temp_shellcode program should send the necessary CAN packets to control the temperate gauge.	\$ gcc -o temp_shell temp_shell.c \$ ls -l temp_shell -rwxrwxr-x 1 craig craig 8722 Jan 6 07:39 temp_shell \$ ./temp_shell  Now run candump in a separate window on vcan0, as shown in the next listing. The temp_shell program should send the necessary CAN packets to control the temperate gauge.	Print 5
207	The main ID is the common ID with the shortest average interval—in this case, signal 0x143 at 0.009998 ms.	The main ID is the common ID with the shortest average interval—in this case, signal 0x143 at 0.009998 s.	Print 5
211	In FSK, a high-frequency signal is a 0, and a low-frequency signal is a 1.	In FSK, a high-frequency signal is a 1, and a low-frequency signal is a 0.	Print 5
236	The two <b>empty</b> 28-pin sockets in the lower-left corner have been added to the original ECU.	The two 28-pin sockets in the lower-left corner have been added to the original ECU.	Print 3